

# SW-A Load Controller Quick Start

(for use with Windows XP\*, Vista, Windows Server 2008, 2012, Windows 7, 8, 8.1 or Windows 10)

\*XP requires Service Pack 3

- (1) Click on the Install MS. Net App button to install the program. If you are connecting to a USB port, you will also need to install the USB com driver.
- (2) The default com port and baud rate is Com 1 and 9,600 baud (8 data bits, no parity, 1 or 2 stop bits). If you are using a different com port or baud rate, you will be prompted to change when you start the SW-A software. The com port and baud rate setting may be changed by double clicking on the in the com port or baud rate label.
- (3) Start the SW-A Load Programmer from the Start button or from the desktop shortcut. The current day relay status will be displayed inside the Relays frame (load on is green, load off is red\*). The Events frame will display the relay events for Relay 1. Com port and baud rate are displayed above. Click on the Setup button to set the SW-A software for the device that you are using. Test your relays by clicking on the relay buttons.

To display or set events for different relays, click on the relay label.

To display or set events for different days of the week, click on the day.

To add an on time for the current relay and day of week, dial in the time using the pull down arrow (hours are in 24 hour format) and click the green button.

To add an off time for the current relay and day of week, dial in the time using the pull down arrow (hours are in 24 hour format) and click the red button.

To delete an event time, select the time (time will turn white) and click Delete.

To rename a relay, click the Setup button and change. Click the Apply button for changes to take effect (and save).

To set a holiday or special event date, click the Setup button and add using the pull down arrows. The regular day of week schedule is suspended on the holiday date and the holiday schedule will be implemented. Click the Apply button for changes to take effect (and save).

To copy all time events for the current day and relay, click Copy.

To paste all time events to the current day and relay, click Paste.

To exit the SW-A program, click on the red X on the top right of your screen. All time functions will stop and all relays will remain in their current state.

Com port, baud rate, device and relay labels may also be changed by editing the swa-set.ini file in the eeci/swa-load folder on your C: drive (use notepad for edits). In the event that the file becomes damaged, just delete the file and a new file will be created when the SW-A program is started.

\* each relay has normally open (NO) and normally closed (NC) contacts. You will typically connect to the NC contacts so your load will be on when the relay is not energized. This allows all your loads to remain on when power is removed from your system.

Complete Technical Reference is located on your Installation CD  
Call (937) 349-6000 or (800) 842-7714 for free technical support

Electronic Energy Control Inc.  
(800) 842-7714    [www.eeci.com](http://www.eeci.com)